HANDSET TUNING GUIDE

POWRTOUCH | CDFMD SPEC

IMPORTANT SAFETY WARNING

Ensure the rollers are OFF the tyres before proceeding.



STEP 01

POWER ON

Switch on the mover electronics with the red isolator key. The green light on the electronics will illuminate.



STEP 02

INSERT THE PIN

Insert a non-metallic pin (cocktail stick or aerial lead) into the hole marked with a little aerial symbol.



STEP 03

START PAIRING

Press the stick down and release. The red and green lights will flash alternately.

HANDSET TUNING GUIDE

POWRTOUCH | CDFMD SPEC

Complete the handset pairing



STEP 04

SWITCH ON HANDSET

Switch the handset on by pressing both green buttons and immediately release.



STEP 05

CONFIRM CONNECTION

The handset will complete its start-up procedure. The green light on the electronics box will then turn solid green.

PAIRING COMPLETE

The handset is now mapped into the electronics.